

## ESSENTIA, MINI, NEOLITO

### RETIREZ TIROIR/REMOVE DRAWER

Ouvrez le tiroir au maximum  
Appuyez sur la gachette sous le tiroir, à l'endroit indiqué  
Tirez

*Open the drawer as far as possible  
Press the trigger under the drawer, where indicated  
Pull*



### AJUSTEMENT HAUTEUR/HEIGHT ADJUSTMENT

Utilisez le mecanisme pour ajuster la hauteur

*Use the mecanism to adjust the height*



### AJUSTEMENT FAÇADE - PETIT TIROIR/DRAWER FRONT ADJUSTMENT - SMALL DRAWER

Dévissez PARTIELLEMENT les 2 vis  
Ajustez horizontalement et verticalement  
Reserrez

*Partially unscrew the 2 screws  
Adjust horizontally and vertically  
Tighten*




## ESSENTIA, MINI, NEOLITO

### AJUSTEMENT FAÇADE - GRAND TIROIR/DRAWER FRONT ADJUSTMENT - LARGE DRAWER

Dévissez PARTIELLEMENT les 4 vis  
Ajustez horizontalement et verticalement  
Reserrez

*Partially unscrew the 4 screws  
Adjust horizontally and vertically  
Tighten*



Vis de fixation  
Fastening screw



Vis d'ajustement  
Adjustment screw

### RETIREZ FAÇADE/REMOVE DRAWER FRONT

TENIR D'UNE MAIN LA FAÇADE  
Dévissez les vis

*HOLD THE FRONT PANEL WITH ONE HAND  
Unscrew the screws*

