
MINI CHIC | SELECTION

DIMENSIONS, ELECTRICITY AND PLUMBING



A. MAIN LED LIGHTING

Install a recessed Duplex Receptacle 15A-125V (not included) in the wall behind the mirror, powered by a 110V 3/14 wire and connected to the main switch.



D. OPTION GFCI OUTLET

Bring out a 100V 3/14 wire about 16" long, not connected to the main switch.



MINI CHIC SINK-COUNTERTOP

Not sold separately.

12 1/8 10 1/2" 15"

MINI CHIC 12" D

